



50450-5277  
28cm PLATE  
D285mm/H33mm



50450-5278  
24cm PLATE  
D243mm/H33mm



50450-3470  
24cm SOUP PLATE  
D237mm/H53mm



50450-3473  
16cm BOWL  
D158mm/H61mm



51396-5662  
27cm PLATE  
D277mm/H27mm



51396-5663  
23cm PLATE  
D236mm/H24mm



51290-5609  
27cm AMUSE PLATE  
D269mm/H17mm



51327-5646  
27cm PLATE  
L268mm/S216mm/H50mm



51327-5647  
22cm PLATE  
L222mm/S196mm/H35mm



51327-5648  
17cm PLATE  
L175mm/S148mm/H27mm



51327-2883  
14cm BOWL  
L143mm/S122mm/H58mm



51091-5506  
33cm SCORE PLATE  
L331mm/S303mm/H31mm



51091-5507  
30cm SCORE PLATE  
L299mm/S269mm/H29mm



51091-5508  
19cm SCORE PLATE  
L189mm/S171mm/H21mm



51091-5600  
15cm SCORE PLATE  
L152mm/S129mm/H17mm



51091-5509  
42cm OBLONG TRAY  
L419mm/S173mm/H35mm



51091-5553  
32cm DOUBLE SPOON TRAY  
L325mm/S142mm/H35mm



51091-5554  
25cm SPOON TRAY  
L252mm/S111mm/H36mm



51091-9786  
12cm SPOON  
L110mm/S47mm/H19mm




51395-5628  
20cm OBLONG TRAY  
L197mm/S197mm/H24mm




51395-5661  
28cm OBLONG TRAY  
L283mm/S130mm/H24mm

# ACCESSORY



**50131-5604**  
16cm L TRAY  
L163mm/S130mm/H14mm

**50131-5605**  
24cm L TRAY  
L239mm/S130mm/H14mm



**50131-5353**  
27cm SQUARE RIM PLATE  
L275mm/S275mm/H10mm




**50131-5599**  
24cm SQUARE RIM PLATE  
L240mm/S240mm/H13mm



**50131-5399**  
17cm SQUARE RIM PLATE  
L175mm/S175mm/H12mm



**8725-9752**  
12cm SQUARE TRAY  
L120mm/S120mm/H15mm



**8725-9749**  
26cm OBLONG TRAY  
L263mm/S192mm/H15mm



**51299-5601**  
8cm SQUARE TRAY  
L80mm/S80mm/H13mm



**51299-5602**  
16cm SQUARE DIVIDED TRAY  
L160mm/S80mm/H13mm



**50131-5603**  
25cm OBLONG TRAY  
L250mm/S85mm/H17mm



**9795-1455**  
31cm OBLONG PLATTER  
L315mm/S226mm/H29mm



**9795-1454**  
25cm OBLONG PLATTER  
L255mm/S179mm/H26mm



**9795-9279**  
23cm OBLONG PLATTER  
L236mm/S142mm/H23mm




**51299-5523**  
30cm SQUARE 6 DIVIDED TRAY  
L300mm/S200mm/H15mm



**51290-5611**  
FOUR DIVIDED DISH  
L201mm/S201mm/H14mm



**50131-5658**  
27cm SQUARE 4 DIVIDED PLATE  
L267mm/S267mm/H18mm  
**50131-5659**  
18cm SQUARE 4 DIVIDED PLATE  
L180mm/S180mm/H18mm



51299-9798  
7cm SMALL STAND  
L70mm/S70mm/H24mm

51300-9797  
7cm SMALL STAND  
L68mm/S68mm/H24mm



50460-9678  
ROSE CUP  
D69mm/H87mm



8531-2741  
TEA CUP  
D65mm/H66mm  
100cc



50460-2657  
PETIT CUP  
D65mm/H54mm  
80cc




50131-9800  
SQUARE AMUSE CUP  
L48mm/S48mm/H77mm



51290-9802  
AMUSE CUP(HIGH)  
L34mm/S34mm/H58mm  
40cc



51290-9803  
AMUSE CUP(LOW)  
L45mm/S45mm  
H30mm/30cc



50131-9799  
CUBE OBJECT  
L122mm/S107mm/H78mm



50460-9716  
10cm TEARDROP BOX  
W/COVER  
L105mm/S95mm/H63mm



50460-9712  
11cm TEARDROP BOAT  
L112mm/S72mm/H35mm



50460-9713  
10cm PEAR BOAT  
L107mm/S75mm/H30mm



50460-9714  
11cm OVAL BOAT  
L110mm/S88mm  
H40mm



50460-9715  
9cm DRESSING BOAT  
L98mm/S81mm  
H45mm/110cc



50827-4589  
CREAMER JUG 100cc  
L89mm/S62mm  
H43mm/100cc



50460-98122  
COVER FOR ROUND BOX  
D60mm/H17mm



50460-96572  
COVER FOR PEACH BOX  
D59mm/H32mm



50460-96582  
COVER FOR PUMPKIN BOX  
D67mm/H33mm



50460-96562  
COVER FOR WOVEN BOX  
L67mm/S60mm/H24mm



50827-45882  
COVER FOR 7cm PETIT BOWL  
L77mm/S67mm/H33mm

50460-98121  
ROUND BOX  
D60mm/H27mm

50460-96571  
PEACH BOX  
D63mm/H39mm

50460-96581  
PUMPKIN BOX  
D67mm/H28mm

50460-96561  
WOVEN BOX  
L66mm/S59mm/H29mm

50827-45881  
7cm PETIT BOWL  
L73mm/S62mm/H43mm/100cc



50460-96762  
COVER FOR RIBBON BOX  
D65mm/H23mm



50460-96752  
COVER FOR POUCH BOX  
L68mm/S58mm/H35mm



50460-9655  
SQUARE BOX W/COVER  
L79mm/S79mm/H65mm



50460-9654  
10cm PETIT TRAY  
L105mm/S70mm/H13mm



50460-2686  
AMUSE CUP  
L106mm/S86mm  
H65mm/210cc

50460-96761  
RIBBON BOX  
D64mm/H35mm

50460-96751  
POUCH BOX  
L70mm/S60mm/H38mm



50576-9701  
ESCARGOT DISH  
L130mm/S100mm/H35mm



50576-9702  
MOULE DISH  
L157mm/S90mm/H24mm



50576-9703  
ABALONE DISH  
L128mm/S102mm/H27mm



50576-9704  
OYSTER DISH  
L140mm/S82mm/H30mm



50576-9705  
SHELL DISH  
L120mm/S100mm/H39mm



50460-9653  
LEAF DISH  
L114mm/S99mm/H25mm



50460-9651  
SHELL DISH  
L92mm/S86mm/H35mm



50460-9652  
ROSE DISH  
L86mm/S83mm/H24mm



51091-9786  
12cm SPOON  
L110mm/S47mm/H19mm



51298-9813  
11cm SPOON  
L114mm/S38mm/H39mm



9795-9544  
AMUSEMENT SPOON  
L105mm/S39mm/H34mm



50180-35332  
COVER FOR 25cm MUFFIN DISH  
D178mm/H91mm

9795-32704  
25cm MUFFIN DISH  
D258mm/H33mm



50180-35342  
COVER FOR 23cm MUFFIN DISH  
D174mm/H84mm

9795-33154  
23cm MUFFIN DISH  
D230mm/H33mm



50180-35352  
COVER FOR 20/26cm MUFFIN DISH  
D147mm/H71mm

9795-32874  
20cm MUFFIN DISH  
D199mm/H37mm



9795-33612  
COVER FOR 25cm MUFFIN DISH  
D178mm/H91mm

9795-32704  
25cm MUFFIN DISH  
D258mm/H33mm



9795-33362  
COVER FOR 23cm MUFFIN DISH  
D174mm/H84mm

9795-33154  
23cm MUFFIN DISH  
D230mm/H33mm



9795-33412  
COVER FOR 20cm MUFFIN DISH  
D147mm/H71mm

9795-32874  
20cm MUFFIN DISH  
D199mm/H37mm



50450-34722  
COVER FOR 19cm PETAL BOWL  
L156mm/S136mm/H56mm

50450-34721  
19cm PETAL BOWL  
L190mm/S159mm/H58mm

50450-3474  
14cm PETAL BOWL  
L148mm/S125mm/H39mm

50460-9679  
10cm PETAL DISH  
L100mm/S83mm/H28mm

51031-27712  
COVER FOR 13cm SOUP BOWL  
D106mm/H84mm

51031-27711  
13cm SOUP BOWL  
L136mm/S125mm/H51mm/210cc

51031-27802  
COVER FOR 10cm PETIT BOWL  
D70mm/H38mm

51031-27801  
10cm PETIT BOWL  
L100mm/S88mm/H43mm/40cc



50180-35852  
COVER FOR 11cm CUP  
D113mm/H48mm

50180-26561  
11cm CUP  
D110mm/H64mm

50180-26562  
COVER FOR 11cm CUP  
D113mm/H46mm

50180-26561  
11cm CUP  
D110mm/H64mm

50828-27382  
COVER FOR PLAIN CUP  
D102mm/H33mm

50828-27381  
PLAIN CUP  
D98mm/H75mm/250cc

50828-27392  
COVER FOR RELIEF CUP  
D110mm/H35mm

50828-27391  
RELIEF CUP  
D105mm/H58mm/220cc

50180-5331  
COMMON SAUCER  
D180mm/H15mm



50828-5386  
14cm SQUARE DISH  
D157mm/L143mm  
S143mm/H31mm

50828-5385  
22cm SQUARE DISH  
D242mm/L220mm  
S220mm/H44mm

50481-2680  
CAFE AU LAIT BOWL(S)  
D112mm/H72mm/380cc

50481-3507  
CAFE AU LAIT BOWL(L)  
D141mm/H80mm/630cc

50180-3408  
13cm LEAF BOWL  
L131mm/S75mm/H31mm



8531-2685  
MUG  
L123mm/S94mm  
H114mm/370cc

8531-9788  
MUG COVER W/ KNOB  
D87mm/H20mm  
8531-2731  
MUG  
L115mm/S94mm  
H112mm/370cc

8531-2689  
MUG  
L117mm/S78mm  
H100mm/370cc

8531-2684  
MUG  
L113mm/S78mm  
H100mm/370cc

51090-9811  
MUG COVER W/ KNOB  
D87mm/H20mm  
8531-2530  
MUG  
L116mm/S92mm  
H90mm/310cc

50481-2633  
MUG  
L113mm/S81mm  
H101mm/370cc

8531-9789  
MUG COVER W/ O KNOB  
D87mm/H8mm  
50481-2697  
MUG  
L115mm/S94mm  
H88mm/280cc



8531-2616  
MUG  
L127mm/S92mm  
H100mm/490cc

51298-2823  
MUG  
L130mm/S93mm  
H95mm/460cc

51180-2815  
MUG  
L112mm/S90mm  
H110mm/400cc

8531-2834  
MUG  
L120mm/S95mm  
H100mm/350cc

8531-2898  
SHORT MUG  
L106mm/S77mm  
H78mm/240cc

51592-2880  
MUG(Stackable)  
L111mm/S81mm  
H94mm/300cc

8531-2900  
MUG  
L117mm/S91mm  
H103mm/430cc



51180-2816  
MUG  
L127mm/S90mm  
H80mm/350cc

51180-2817  
MUG  
L110mm/S84mm  
H80mm/270cc

50617-2696  
MUG  
L117mm/S91mm  
H84mm/280cc

50460-2686  
AMUSE CUP  
L106mm/S86mm  
H65mm/210cc

8531-2741  
TEA CUP  
D65mm/H66mm/100cc

50481-2678  
FREE CUP(S)  
D85mm/H65mm/140cc

50481-2677  
FREE CUP(L)  
D81mm/H123mm/250cc



8531-2639  
CAPPUCCINO CUP  
L150mm/S125mm  
H74mm/540cc

9795-2918  
COFFEE CUP(Stackable)  
L110mm/S96mm  
H70mm/260cc

9772-2455  
COFFEE CUP  
L118mm/S92mm  
H72mm/210cc

9772-2229  
TEA CUP  
L123mm/S98mm  
H64mm/210cc

51592-2881  
TEA/ COFFEE CUP(Stackable)  
L105mm/S90mm/H65mm/230cc

8531-5056  
19cm SAUCER  
D189mm/H17mm

9795-1452  
COMMON SAUCER  
D155mm/H21mm

9772-1394  
16cm SAUCER  
D162mm/H19mm

9772-1394  
16cm SAUCER  
D162mm/H19mm

51592-5720  
15cm SAUCER  
D150mm/H16mm



9795-2390  
BOUILLON CUP(Stackable)  
L140mm/S101mm  
H53mm/310cc

9795-2389  
COFFEE CUP(Stackable)  
L106mm/S85mm  
H57mm/230cc

9795-2392  
ESPRESSO CUP(Stackable)  
L83mm/S65mm  
H51mm/110cc

9795-1452  
COMMON SAUCER  
D155mm/H21mm

9795-1452  
COMMON SAUCER  
D155mm/H21mm

9795-1453  
ESPRESSO SAUCER  
D125mm/H20mm

# ACCESSORY



92626-9832  
CHINESE WINE CUP  
D40mm/H82mm/25cc



9265-9830  
6cm SQUARE BOWL(Stackable)  
L62mm/S62mm/H32mm

9265-9839  
26cm CASTER TRAY(4 PORTIONS)  
L266mm/L72mm/H15mm



9265-9830  
6cm SQUARE BOWL(Stackable)  
L62mm/S62mm/H32mm

9265-9829  
20cm CASTER TRAY(3 PORTIONS)  
L200mm/S71mm/H15mm



9795-42482  
SMALL CUP COVER  
D70mm/H29mm

9795-9447  
SMALL CUP(1-pc)(Stackable)  
D68mm/H33mm/80cc



92626-331  
MUSTARD POT  
D68mm/H40mm/60cc



9795-4361  
MARMALADE POT  
D60mm/H61mm/80cc



9265-508  
CRESCENT DISH  
L207mm/S143mm/H23mm



9795-9484  
15cm CASTER TRAY  
L153mm/S88mm/H10mm



92626-9515  
25cm CASTER TRAY(3 PORTIONS)  
L248mm/S83mm/H15mm



9795-9785  
ASHTRAY  
L151mm/S121mm  
H26mm



9795-9429  
ASHTRAY  
D89mm/H33mm



9795-901  
ASHTRAY  
D132mm/H22mm



9795-900  
SOAP DISH  
L125mm/S87mm  
H21mm



9795-675  
BUD VASE  
D71mm/H126mm



92626-9323  
TOOTHPICK HOLDER  
D54mm/H46mm



8531-9286  
NAPKIN RING  
L48mm/S24mm  
H42mm



50481-9695  
SALT SHAKER  
(3HOLES)  
D61mm/L52mm  
S52mm/H82mm



50481-9696  
PEPPER SHAKER  
(5HOLES)  
D61mm/L52mm  
S52mm/H82mm



9795-9558  
SALT SHAKER  
(3HOLES)  
D46mm/H90mm



9795-9559  
PEPPER SHAKER  
(5HOLES)  
D46mm/H90mm



8531-9318  
SALT SHAKER  
(3HOLES)  
L54mm/S41mm  
H85mm



8531-9319  
PEPPER SHAKER  
(5HOLES)  
L54mm/S41mm  
H85mm



9795-9466  
SALT SHAKER  
(3HOLES)  
D43mm/H54mm



9795-9467  
PEPPER SHAKER  
(5HOLES)  
D43mm/H54mm



9772-9314  
SALT SHAKER  
(3HOLES)  
L53mm/S40mm  
H72mm



9772-9313  
PEPPER SHAKER  
(5HOLES)  
L53mm/S40mm  
H72mm



9795-9211  
EGG CUP  
D52mm/H60mm



9795-3189  
SAUCE BOAT(1-P)  
L119mm/S65mm  
H43mm/110cc




9795-3249  
DRESSING BOAT  
L210mm/S93mm/H92mm/340cc



50786-5354  
14cm PLATE(Relief)  
D170mm/L145mm  
S145mm/H23mm



50576-9721  
SMALL SQUARE DISH  
L110mm/S102mm/H12mm



51299-5601  
8cm SQUARE TRAY  
L80mm/S90mm/H13mm



50481-5615  
SQUARE BUTTER DISH  
D95mm/L81mm  
S81mm/H12mm



50481-3573  
15cm OBLONG TRAY  
L154mm/S83mm/H15mm



92626-9780  
ROUND DIVIDED DISH  
(Stackable)  
D95mm/H20mm



92626-9428  
DIVIDED DISH  
L87mm/S87mm/H19mm



9795-9380  
DIVIDED DISH  
L150mm/S102mm  
H28mm



9265-9781  
5 COMPARTMENT DISH  
L260mm/S79mm/H27mm



9265-9782  
3 COMPARTMENT DISH  
L170mm/S79mm/H27mm



8531-1597  
10cm BUTTER DISH  
D103mm/H21mm



9795-9277  
9cm BUTTER DISH  
D95mm/H14mm



9795-973  
8cm DIP DISH  
D82mm/H25mm



92626-1690  
7cm SAUCE DISH  
D71mm/H20mm/40cc



9265-9453  
LADLE  
L172mm/S63mm



51298-9808  
SPOON  
L175mm/S40mm  
H28mm



50576-9688  
LEAF SPOON(M)  
L131mm/S21mm/H16mm



50576-9689  
LEAF SPOON(L)  
L84mm/S16mm/H11mm



50460-9707  
BABY SPOON  
L81mm/S33mm  
H29mm



50576-9706  
LEAF SPOON(L)  
L162mm/S32mm  
H22mm



50460-9674  
LEAF SPOON(S)  
L125mm/S40mm  
H22mm



92626-9536  
SPOON  
L145mm/S36 mm/H43mm



50576-9683  
STAR REST  
L65mm/S58mm/H10mm



50576-9680  
GINKGO REST  
L88mm/S87mm /H19mm



50576-9681  
ELM REST  
L122mm/S47mm /H21mm



50576-9573  
LEAF REST  
L115mm/S60mm/H35mm



50576-9682  
EUCALYPTUS REST  
L57mm/S47mm/H47mm



50576-9722  
AMUSE REST  
L49mm/S28mm  
H21mm



50576-9684  
2 STEPS REST  
L75mm/S20mm  
H11mm



50576-9685  
3 STEPS REST  
L90mm/S20mm  
H18mm



50576-9686  
2 SQUARES REST  
L56mm/S30mm  
H10mm



50576-9687  
3 SQUARES REST  
L80mm/S30mm  
H10mm



50576-9833  
10cm 3 SQUARES REST  
L100mm/S37mm/H11mm



92626-9834  
CHOPSTICKS & SPOON REST  
L103mm/S36mm/H10mm



92626-9334  
CHOPSTICKS REST  
L61mm/S18mm/H12mm



92626-9468  
CHOPSTICKS & SPOON REST  
L110mm/S55mm/H15mm



51298-9810  
CHOPSTICKS & SPOON REST  
L130mm/S42mm  
H12mm



50763-2809  
10cm BOWL(Stackable)  
D101mm/H53mm/310cc



9795-2838  
10cm BOWL(Stackable)  
D101mm/H53mm/310cc



51298-4643  
SUGAR CONTAINER  
L110mm/S80mm/ H53mm  
160cc



9795-795  
SUGAR CONTAINER  
L80mm/S77mm/H45mm



8531-4562  
CREAMER JUG 120cc  
L102mm/S43mm/ H68mm  
120cc



8725-2916  
FREE CUP 170cc  
D76mm/H77mm/170cc



8725-2917  
FREE CUP 320cc  
D91mm/H100mm/320cc



9265-4515  
PETIT POT  
W/COVER  
L143mm/S90mm  
H100mm/330cc



92626-4362  
TEA POT W/ COVER 730cc  
L168mm/S136mm/H105mm/ 730cc



9265-3612  
THAI CURRY POT W/ COVER 1100cc  
L190mm/S160mm/H150mm/1100cc



9265-3611  
INDIAN CURRY POT W/COVER 900cc  
D190mm/H110mm/900cc



9265-3610  
BRIYANI POT W/COVER 1000cc  
D168mm/H138mm/1000cc




9265-9842  
CURRY/BRIYANI POT STAND  
D145mm/H68mm



50481-3525  
30cm ROUND 2 DIVIDED PLATE  
L303mm/S275mm/H25mm



9265-5738  
36cm OBLONG TRAY  
L360mm/S210mm/H20mm



9265-5710  
35cm OBLONG TRAY  
L350mm/S160mm/H18mm  
9265-5709  
28cm OBLONG TRAY  
L280mm/S140mm/H18mm