



50180 White



50657 Pearl Gold



50658 Pearl Silver



50767 White(Mat&Shiny)
(ITEM No.BB)



50829 White (Mat)
(ITEM No.BA)
Available for hollowware only



50180-5220
30cm SERVICE PLATE
D301mm/H28mm



50180-5312
30cm ROUND PLATE
D300mm/H22mm



50180-5242
27cm ROUND PLATE
D276mm/H21mm



50180-5243
23cm ROUND PLATE
D233mm/H20mm



50180-5244
21cm ROUND PLATE
D208mm/H15mm



50180-5245
18cm ROUND PLATE
D180mm/H15mm



50180-5703
16cm ROUND PLATE
D159mm/H12mm



50180-35352
COVER FOR 26cm MUFFIN PLATE
D147mm/H71mm

50180-5221
26cm MUFFIN PLATE
D263mm/H50mm



50180-5219
27cm DEEP PLATE
D273mm/H45mm



50180-3452
23cm DEEP PLATE
D228mm/H37mm



50180-5304
23cm SOUP BOWL
D233mm/H34mm



50180-3497
22cm BOWL
D220mm/H96mm



50180-3515
19cm BOWL
D195mm/H80mm



50180-3554
16cm BOWL
D165mm/H64mm



50180-5313
14cm BOWL
D140mm/H56mm

50180-5704
16cm SAUCER
D161mm/H14mm



50180-3565
13cm BOWL
D133mm/H53mm/370cc



50180-28782
COVER FOR 10cm BOWL
D110mm/H38mm

50180-2699
10cm RICE BOWL
D107mm/H58mm/230cc

ESPRIT
50180 White



50180-2687
TEA CUP
L127mm/S107mm/H51mm/230cc
50180-5305
COMMON SAUCER
D166mm/H19mm



50180-2703
COFFEE CUP
L113mm/S90mm/H65mm/210cc
50180-5305
COMMON SAUCER
D166mm/H19mm



50180-2690
ESPRESSO CUP
L90mm/S67mm/H60mm/100cc
50180-5315
ESPRESSO SAUCER
D123mm/H17mm



50180-2774
CAPPUCCINO CUP
L139mm/S112mm/H66mm/350cc
50180-5305
COMMON SAUCER
D166mm/H19mm



50180-4563
SUGAR BOWL
W/COVER
D114mm/H103mm/340cc



50180-2877
SUGAR BOWL
W/COVER 270cc
D99mm/H98mm/270cc



50180-4564
CREAMER JUG 220cc
L136mm/S90mm
H71mm/220cc



50180-4581
CREAMER JUG 160cc
L110mm/S86mm
H68mm/160cc



50180-2688
MUG
L120mm/S93mm
H102mm/370cc



50180-2688
MUG
L120mm/S93mm
H95mm/370cc
50180-5705
17cm SAUCER
D168mm/H18mm



50180-4565
TEA/COFFEE POT W/COVER(L)
L272mm/S162mm
H163mm/1,270cc



50180-4628
TEA/COFFEE POT W/COVER(M)
L235mm/S142mm
H128mm/800cc



50180-4654
TEA POT W/COVER 550cc
L219mm/S129mm
H115mm/550cc



50180-4580
COFFEE POT W/COVER 700cc
L208mm/S110mm
H148mm/700cc



50180-4653
COFFEE POT W/COVER 530cc
L192mm/S100mm
H139mm/525cc



50180-27092
COVER FOR BOUILLON CUP
D138mm/H40mm
50180-27091
BOUILLON CUP
L148mm/S133mm/H53mm/370cc
50180-5331
BOUILLON SAUCER
D180mm/H15mm



50180-54302
CHAPPE SET
92626-93392
COVER FOR CHAPPE
D85mm/H25mm
50180-2837
CHAPPE CUP
D98mm/H67mm/240cc
92626-9416
CHAPPE SAUCER
D102mm/H24mm




50180-2708
9cm FREE CUP
D92mm/H61mm/210cc



50180-35852
COVER FOR 11cm CUP
D113mm/H48mm
50180-26561
11cm CUP
D110mm/H64mm



50180-3561
19cm COVERED SOUP BOWL W/HANDLE
L235mm/S194mm/H126mm/1,260cc



50180-3598
22cm SQUARE TRAY
L217mm/S217mm/H28mm

50180-3450
28cm SQUARE TRAY
L285mm/S285mm/H30mm

50180-3449
43cm OBLONG TRAY
L437mm/S155mm
H30mm

50180-3448
28cm OBLONG TRAY
L287mm/S154mm/H30mm

50180-9718
23cm OVAL TRAY
L234mm/S129mm/H16mm

50180-5314
38cm OVAL PLATTER
L385mm/S207mm/H40mm

50180-5555
43cm OVAL PLATTER
L443mm/S246mm/H41mm

50180-3431
12cm SQUARE TRAY
L123mm/S123mm/H22mm

50180-3430
33cm SQUARE TRAY
L339mm/S339mm/H36mm