

NEW RIM

- 51635** Red Background
- 51636** White Background
- 96316** Mix and Match



51806



- 51604** Blue Background
- 51605** White Background
- 96317** Mix and Match



51605 White Background



51401
50518



51527



51608



51606





8531-1670
30cm PLACE PLATE
D304mm/H21mm

8531-1557
27cm DINNER PLATE
D269mm/H24mm

8531-1269
23cm BRUNCH PLATE
D228mm/H20mm

8531-1086
21cm SALAD PLATE
D212mm/H17mm

8531-1558
19cm CAKE PLATE
D191mm/H17mm

8531-1214
16cm B.B. PLATE
D167mm/H14mm



8531-1646
23cm RIM SOUP PLATE
D227mm/H36mm/350cc

8531-5762
17.5cm MEZZA BOWL (DEEP)
D175mm/H53mm

8531-5763
17cm MEZZA BOWL
D168mm/H45mm

8531-5764
13cm MEZZA BOWL
D129mm/H36mm

8531-1857
13cm FRUIT BOWL
D130mm/H44mm



8531-2438
TEA CUP
L125mm/S100mm/H62mm/230cc

8531-2423
TEA/COFFEE CUP
L109mm/S87mm/H74mm/240cc

8531-2427
ESPRESSO CUP
L88mm/S68mm/H59mm/110cc

8531-2428
BOUILLON CUP
L151mm/S120mm/H53mm/340cc

8531-1597
10cm BUTTER DISH
D103mm/H21mm

8531-1217
TEA/COFFEE SAUCER
D158mm/H19mm

8531-1217
TEA/COFFEE SAUCER
D158mm/H19mm

8531-1222
ESPRESSO SAUCER
D124mm/H18mm

8531-1218
BOUILLON SAUCER
D177mm/H22mm



8531-4359
COFFEE POT W/COVER
L251mm/S141mm
H215mm/1,320cc

8531-4416
TEA POT W/COVER
L250mm/S152mm
H145mm/940cc

8531-4464
TEA POT
W/COVER(1-P)
L200mm/S124mm
H127mm/550cc

8531-4358
SUGAR BOWL
W/COVER
L133mm/S111mm
H109mm/300cc

8531-4357
CREAMER JUG 220cc
L122mm/S87mm
H99mm/220cc

8531-4414
CREAMER JUG 200cc
L114mm/S81mm
H86mm/200cc



8531-32821
GRAVY BOAT 560cc
L218mm/S97mm/H115mm

9265-4515
PETIT POT W/COVER
L143mm/S90mm
H100mm/330cc

8531-9318
SALT SHAKER
(3HOLES)
L54mm/S41mm
H85mm

8531-9319
PEPPER SHAKER
(5HOLES)
L54mm/S41mm
H85mm

8531-9286
NAPKIN RING
L48mm/S24mm
H42mm

8531-2685
MUG
L123mm/S94mm
H114mm/370cc

8531-2898
MUG
L106mm/S77mm
H78mm/240cc

8531-32064
GRAVY BOAT TRAY
L233mm/S145mm/H23mm

8531-59097
GRAVY BOAT W/TRAY
L233mm/S145mm/H125mm

NEW RIM
8531 White



8531-1219
43cm OVAL PLATTER
L434mm/S315mm/H30mm

8531-1220
38cm OVAL PLATTER
L383mm/S271mm/H26mm

8531-1221
32cm OVAL PLATTER
L328mm/S234mm/H26mm

8531-9212
23cm BUTTER TRAY
L224mm/S122mm/H26mm



8531-3279
22cm ROUND
VEGETABLE BOWL
D220mm/H89mm

8531-3281
24cm OVAL
VEGETABLE BOWL
L238mm/S178mm/H73mm

8531-3283
CASSEROLE W/COVER, REGULAR
L248mm/S217mm/H181mm/2,420cc

8531-3356
CASSEROLE W/COVER, LARGE
L275mm/S238mm/H206mm/4,280cc

NEW RIM Millennium Edition
8531 White



8531-2636
TEA/COFFEE CUP
L117mm/S99mm/H63mm/210cc



8531-2637
ESPRESSO CUP
L84mm/S65mm/H66mm/100cc



8531-4529
SUGAR BOWL W/COVER
L153mm/S103mm
H114mm/290cc



8531-4528
CREAMER JUG 190cc
L125mm/S83mm
H89mm/190cc

8531-1155
TEA/COFFEE SAUCER
L149mm/S139mm/H25mm

8531-5191
ESPRESSO SAUCER
L123mm/S116mm/H21mm



8531-4530
COFFEE POT W/COVER
L236mm/S130mm
H228mm/1,430cc



8531-4531
TEA POT W/COVER
L246mm/S154mm
H180mm/1,140cc



8531-3404
CASSEROLE W/COVER, LARGE
L333mm/S250mm/H213mm/4,290cc