





51800-5769  
30cm RIM PLATE  
D304mm/H25mm

51800-5773  
27cm RIM PLATE  
D275mm/H22mm

51800-5770  
30cm COUPE PLATE  
D304mm/H25mm

51800-5774  
27cm COUPE PLATE  
D275mm/H22mm



51800-5777  
23cm COUPE PLATE  
D235mm/H20mm

51800-5778  
21cm COUPE PLATE  
D212mm/H18mm

51800-5779  
19cm COUPE PLATE  
D196mm/H16mm

51800-5780  
16cm COUPE PLATE  
D164mm/H17mm



51799-2911  
COFFEE CUP(PLAIN)  
L110mm/S89mm/H66mm  
210cc

51800-2902  
COFFEE CUP  
L110mm/S89mm/H66mm  
210cc

51799-2914  
TEA CUP(PLAIN)  
L125mm/S105mm/H56mm  
250cc

51800-2904  
TEA CUP  
L125mm/S105mm/H56mm  
250cc

51799-2912  
ESPRESSO CUP(PLAIN)  
L89mm/S70mm/H57mm  
110cc

51800-2901  
ESPRESSO CUP  
L89mm/S70mm/H57mm  
110cc

51800-5784  
16cm SAUCER  
D164mm/H19mm

51800-5783  
13cm SAUCER  
D133mm/H15mm



51799-2913  
BOUILLON CUP(PLAIN)  
L150mm/S110mm/H54mm  
260cc

51800-2907  
BOUILLON CUP  
L150mm/S110mm/H54mm  
260cc

51799-2915  
CAPPUCCINO CUP(PLAIN)  
L137mm/S113mm/H63mm  
330cc

51800-2909  
CAPPUCCINO CUP  
L137mm/S113mm/H63mm  
330cc

51799-2903  
COFFEE CUP(Stackable/PLAIN)  
L105mm/S81mm/H64mm  
240cc

51800-5784  
16cm SAUCER  
D164mm/H19mm



51800-36132  
COVER FOR SOUP CUP  
D125mm/H41mm

92626-32681  
SOUP CUP 340cc  
L142mm/S121mm/H56mm/340cc

51800-5793  
18cm SAUCER  
D178mm/H20mm



51800-5772  
29cm PASTA PLATE  
D297mm/H46mm



51800-5776  
24cm RIM SOUP PLATE  
D241mm/H42mm



51800-5781  
10cm SAUCE DISH  
D105mm/H16mm



51800-4692  
CREAMER JUG 180cc  
L89mm/S67mm  
H93mm/180cc



51800-3600  
17cm BOWL  
D169mm/H42mm



51800-3602  
10cm BOWL  
D108mm/H54mm/230cc



51800-3607  
9cm BOWL  
D96mm/H46mm



51800-4687  
TEA POT  
W/COVER 840cc  
L223mm/S142mm/H108mm/840cc



51800-4691  
SUGAR BOWL  
W/COVER 250cc  
D96mm/H77mm/250cc



51800-2910  
9cm SUGAR BOWL  
D90mm/H43mm/160cc